



**TOOL MODEL: TTX-5**  
**PRESSURE/TORQUE CONVERSION CHART**



**Standard Torque Chart**

<b>PRESSURE IN PSI</b>	<b>FT. LBS.</b>	<b>TORQUE IN</b>		<b>PRESSURE IN BAR</b>
		<b>KGM</b>	<b>NM</b>	
1500	866	120	1174	104
1600	925	128	1253	110
1800	1042	144	1412	124
2000	1159	160	1571	138
2200	1278	177	1732	152
2400	1397	193	1893	165
2600	1515	210	2054	179
2800	1634	226	2215	193
3000	1753	242	2376	207
3200	1871	259	2536	220
3400	1989	275	2696	234
3600	2107	291	2856	248
3800	2225	308	3016	262
4000	2343	324	3176	276
4200	2462	340	3337	290
4400	2581	357	3499	303
4600	2700	373	3660	317
4800	2819	390	3821	331
5000	2938	406	3983	345
5200	3059	423	4146	358
5400	3179	440	4310	372
5600	3300	456	4473	386
5800	3420	473	4637	400
6000	3541	490	4800	414
6200	3661	506	4963	427
6400	3781	523	5126	441
6600	3902	540	5289	455
6800	4022	556	5452	468
7000	4142	573	5615	482
7200	4264	590	5780	496
7400	4386	607	5945	510
7600	4507	623	6110	524
7800	4629	640	6275	538
8000	4751	657	6440	552
8200	4872	674	6604	565
8400	4992	690	6767	579
8600	5113	707	6931	593
8800	5233	724	7094	607
9000	5354	740	7258	620

---

9200	5475	757	7422	634
9400	5596	774	7585	648
9600	5716	791	7749	662
9800	5837	807	7913	676
10000	5958	824	8077	690

---

REV. 3/8/2017